

DRAFT 4/97

4.12 Test of Reactive-tracer Transport

This test verifies that FEHM has correctly implemented reactive-tracer transport. Figures 48 to 52 show that FEHM results are in good agreement with the SORBEQ solutions. The results, compared numerically to the SORBEQ solutions (found in files *sorbeq_out.cons*, *sorbeq_out.fr*, *sorbeq_out.lang*, *sorbeq_out.lin*, and *sorbeq_out.mfr*) are given in Table 54. The maximum absolute error in concentration for the five isotherms was less than 0.0104, and the percent errors were less than 10% when concentrations were greater than 0.1. These results meet the acceptance criteria for this test suite developed in Chapter III.

Table 54. Results of the test of reactive-tracer transport

V&V test	Maximum error	Maximum % error	RMS error
Concentration versus time at the outlet node			
Conservative	0.9809e-02	9.599	0.2936e-03
Linear	0.4474e-02	2.258	0.1798e-03
Langmuir	0.9049e-02	5.486	0.2411e-03
Freundlich	0.6322e-02	6.252	0.2531e-03
Modified Freundlich	0.1040e-01	3.060	0.2269e-03




Figure 48. Comparison of FEHM and SORBEQ outlet concentrations for the conservative tracer.

DRAFT 4/97




Figure 49. Comparison of FEHM and SORBEQ outlet concentrations for the linear isotherm.




Figure 50. Comparison of FEHM and SORBEQ outlet concentrations for the Langmuir isotherm.

DRAFT 4/97




Figure 51. Comparison of FEHM and SORBEQ outlet concentrations for the Freundlich isotherm.




Figure 52. Comparison of FEHM and SORBEQ outlet concentrations for the modified Freundlich isotherm.